DATAFORTH[®] Analog Input Module: Frequency

DATA ACQUISITION SYSTEMS - MAQ[®]20



Measure Frequencies to 1MHz

DESCRIPTION

The MAQ[®]20-FREQ frequency input module offers 8 input channels for measuring frequencies up to 1MHz. All channels are individually configurable for range and alarm limits to match the most demanding applications. Four controllable outputs can be used for sensor excitation or as 5V logic compatible outputs. High, Low, High-High and Low-Low alarms provide essential monitoring and warning functions to ensure optimum process flow and fail-safe applications. Field I/O connections are made through a pluggable terminal block with positions designated for the termination of wiring shields.

Input-to-bus isolation is a robust 1500Vrms and each individual channel is protected up to 240Vrms continuous overload in case of inadvertent wiring errors.

Channels in a module can be selectively enabled for scanning. All channels are enabled by default; however, non-used channels can be disabled to increase the system sampling rate of enabled channels.

All MAQ20 modules are designed for installation in Class I, Division 2 hazardous locations and have a high level of immunity to environmental noise commonly present in heavy industrial environments.

FEATURES

- 8 Input Channels
- 50mV Sensitivity
- 1Hz to 1MHz plus State Change Frequency Range
- DC + Signal ≤300Vrms Operating Range
- All Channels Individually Configurable for Range and Alarms
- 4 Excitation Sources to Power Sensors or Provide 5V Logic Compatible Output


BENEFITS

- Highly Compact
- Low Cost per Channel
- Modular
 - APPLICATIONS
- Process Control
- Factory Measurement and Control
- Machine Automation

- 1500Vrms Input-to-Bus Isolation
- Each Channel Protected up to 240Vrms
- Selective Enabling of Module Channels for Scanning
- · Heavy Industrial CE Compliant
- UL/cUL (Class I, Div 2, Groups A, B, C, D) File E232858
- ATEX Compliance Pending
- Manufactured per RoHS III Directive 2015/863

On-vehicle/-mobile Use Possible (Wide Power Supply Voltage)

- Open Software Platform Options
- · Easy and Fast Setup/Installation
- Military and Aerospace
 - Scientific Measurement
 and Monitoring
 - Battery Management



MAQ20-FREQ Frequency-input Module Block Diagram

www.dataforth.com

DATAFORTH®

Specifications Typical* at T_A =+25°C and +24VDC System Power

| / | promiting and a second and a second and a second and a second a se |
|---|--|
| Module | Description |
| MAQ20-FREQ Input Signal | 8-channel, Frequency-input, 1Hz to 1MHz, Plus State Change Detect 50mV Sensitivity |
| Excitation | Operating Range: DC + Signal 300Vrms Four 5V Sources at 8mA each Use for Sensor Excitation or 5V Logic Compatible Output |
| Per Channel Setup Input Protection Continuous Transient CMV Channel-to-Bus Channel-to-channel Transient | Individually Configurable for Range, Alarms 240Vrms (max) ANSI/IEEE C37.90.1 1500Vrms, 1 Minute 0V ANSI/IEEE C37.90.1 |
| Resolution and Accuracy Clock Accuracy Clock Accuracy Over Temp | 32 Bits ±0.003% ±0.01%, −40°C to +85°C |
| Scan Rate Alarms Power Supply Current | 1000 Ch/s High / High-High / Low / Low-Low 400mA |
| Dimensions (h)x(w)x(d) | 4.51" x 0.60" x 3.26" (114.6mm x 15.3mm x 82.8mm) |
| Environmental Operating Temperature Storage Temperature Relative Humidity Emissions, EN61000-6-4 Radiated, Conducted Immunity EN61000-6-2 RF ESD, EFT | -40°C to +85°C -40°C to +85°C 0 to 95% Noncondensing ISM Group 1 Class A ISM Group 1 Performance A ±0.5% Span Error Performance B |
| Certifications | Heavy Industrial CE Compliant UL/cUL (Class I, Division 2, Groups A, B, C, D) File E232858 ATEX Compliance Pending |
| | |

Ordering Information

| Model | Description |
|------------|--------------------------------------|
| MAQ20-FREQ | Analog Input Module; Frequency, 8-ch |

| Terminal Block Position (top to bottom) | MAQ20-FREQ I/O Connections |
|--|-------------------------------|
| 1 | CH0 +IN |
| 2 | CH0 –IN |
| 3 | CH1 +IN |
| 4 | CH1 –IN |
| 5 | EXC0 / OUT0 |
| 6 | CH2 +IN |
| 7 | CH2 –IN |
| 8 | CH3 +IN |
| 9 | CH3 –IN |
| 10 | EXC1 / OUT1 |
| 11 | CH4 +IN |
| 12 | CH4 –IN |
| 13 | CH5 +IN |
| 14 | CH5 –IN |
| 15 | EXC2 / OUT2 |
| 16 | CH6 +IN |
| 17 | CH6 –IN |
| 18 | CH7 +IN |
| 19 | CH7 –IN |
| 20 | EXC3 / OUT3 |

NOTES :

*Contact factory or your local Dataforth sales office for maximum values.

For input connections and full details on module operation, refer to: MA1048 – MAQ20 Frequency-input Module Hardware User Manual

www.dataforth.com